EPSON®
EXCEED YOUR VISION

LabelWorks™

Printable Ribbon Kit

User's Guide


Display
Turn on/off
Print
Cut
Repeat design
Add symbols
Delete
Add a frame or other special effect
Shift
Select/Enter
Caps lock
Add an accented letter
Add a space

Contents

Welcome 3

Getting Started 4
- Inserting batteries 4
- Using the optional AC adapter 5
- Inserting a ribbon cartridge 5
- Removing a ribbon cartridge 6

Creating Ribbon Designs 7
- Entering text 7
- Creating long ribbons 7

Saving Ribbon Designs 8
- Deleting ribbon designs 8

Enhancing Your Ribbons 8
- Adding symbols 8
- Adding frames 13
- Changing the font size 15
- Changing the font 15
- Changing the font style 16

Printing Ribbons 16
- Printing multiple copies 17

Customizing Your Ribbons 17
- Creating vertical text 17
- Adding space between characters 18
- Increasing print density 18
- Selecting narrow characters 18
- Adding punctuation 18
- Adding letters with an accent mark 19
- Customizing the length of ribbons 19
- Using mirror-image text 19
- Creating sequentially numbered ribbons . . 20

Sample Projects 20
- Favor bags 20
- Hair bows or ponytail holders 21
- Ornaments with ribbon hangers 22
- Greeting cards 23

Adjusting the Display 23

Cleaning the Printer 24
- Cleaning the print head 24

Solving Problems 25
- Error messages 25
- Problems and solutions 26

Epson Technical Support 28
Recycling 28
Purchase supplies and accessories 28
Registration 29
Specifications 29
Storing Your Kit 30
Notices 31
Safety instructions..... 31
About printed labels..... 33
FCC Compliance Statement..... 33
Epson America, Inc. Limited Warranty 34
Trademarks 36

Welcome

Your LabelWorks Ribbon Kit lets you create personalized ribbons, the perfect accent on gifts and decorations for all occasions.

Add names or custom text to your ribbons along with symbols and frames for special occasions, holidays, hobbies, and more!

Personalized ribbons add the finishing touch to:

- party favors
- wedding and baby showers
- flower arrangements
- bakery gifts
- hair decorations
- toys

Save up to 30 ribbons to reuse at any time. The kit includes two cartridges so you can print over 32 feet of ribbon.

Additional ribbon colors are available, as shown on the back cover of this guide.

With the other types of tape listed on the back cover, you can do even more:

- Create iron-on labels for uniforms, clothing, backpacks, and other fabric items.
- Organize stuff in your kitchen, bathroom, and every room of your house.
- Decorate and personalize school supplies.
- Create professional looking file labels.
- Identify your computer cables and other equipment.

You'll find hundreds of uses for your LabelWorks printer!

Getting Started

Your Label Works printer requires 6 AAA batteries (not included). An optional AC adapter is also available (C52CB73020).

Follow the instructions in this section to insert the batteries and tape cartridge, and change the language if necessary.

Inserting batteries

1. Remove the rear cover.



2. Insert 6 AAA alkaline batteries, positioning the + and - ends as shown.



3. Replace the cover and snap it into place.



Using the optional AC adapter

1. Plug one end of the AC adapter into the product.
2. Plug the other end of the AC adapter into a wall outlet.



Caution: Make sure you use only the AC adapter designed for your LabelWorks printer (C52CB73020) or damage may occur.

Inserting a ribbon cartridge

1. Remove any slack from the ribbon.



2. Remove the rear cover.



3. Insert the cartridge and press it down firmly until it snaps into place.

4. If there is excess ribbon, feed the end through the tape guide slot.



5. Replace the cover and snap it into place.
6. Press ⏻ to turn on the printer.

Removing a ribbon cartridge

1. Remove the rear cover.
2. Hold the cartridge by the tabs, and lift it straight up.



Creating Ribbon Designs

Enter text to begin creating your ribbon design. Then follow the suggestions for adding length if necessary.

Entering text

Use the built-in keyboard to enter letters and numbers.

- Press aA to use upper case for all letters, or ⇧ + character for a single letter.
- Press ⌫ to delete the previous character.
- Press ↵ to start a new line. The line number is indicated on the display.

  Note: You can print a maximum of two lines of text. If you try to exceed the maximum, ▮ appears and you will not be able to print. Press ⌫ to delete the ▮ and print your ribbon.

Creating long ribbons

The number of characters and symbols you can enter is limited, but you can use the following techniques to create longer ribbons:

- Select multiple copies of your design to create a longer ribbon with a repeated pattern. See page 17 for instructions.
- To add length to one end of the ribbon (unprinted), press ⇧ + ⎙ to feed about an inch before printing. Press these buttons repeatedly to add more length.

  Repeat this step after printing to add length to the other end of the ribbon.
- Press the spacebar to add blank spaces between printed areas. Using a larger font will make the ribbon longer.

  Note: You'll see a ◀ black arrow when you get to the character limit. You may have to add or delete spaces to make the design fit.

Saving Ribbon Designs

You can store up to 30 saved ribbons at a time.

After you finish creating your first ribbon, press ⇧ + [▼] to create another ribbon (the ribbon number appears to the left of the text). Your first ribbon is automatically saved.

Deleting ribbon designs

1. Press ⇧ + [▼] or ⇧ + [▲] to select a ribbon design for deletion.
2. Press ⇧ + ⌫. You see a confirmation message.
3. Press ↵ to delete, or press [▼] if you change your mind.

Enhancing Your Ribbons

Get creative by adding symbols or frames to your ribbons and selecting the right font for each design.

Adding symbols

You can add symbols for holidays, activities, special occasions, and more.

1. Press ★△✎.
2. Press [►] to scroll through the symbol categories, then press ↵ to select a category.
3. Press [◄] or [►] to highlight a symbol, then press ↵ to select it.

Note: To cancel and return to the previous menu, press ★△✎.

You can choose from the symbols shown on the following pages.

Symbols

Prohibition

Household

Food

Sports

Activity

Occasion

Shipping

Electrical



Animals

Zodiac

Emoticons

Measurement

℉℃° A V Ω W kW Hz dB HP Å ft′ ″ %

Metric

㎛ mm cm m km c㎡ m㎡ k㎡ c㎥ m㎥ mg g kg mℓ ℓ ℃

Abbreviation

No. & © ® TEL FAX ™

Punctuation

, . · : ; ? ! - ／＼～ @ ~ _ § ¡ ¿

Parentheses

‘ ’ “ ” ( ) 〔 〕 [ ] { } 〈 〉 《 》 「 」 『 』 【 】

Math

＋ － ± × * ÷ = ≠ < > ≦ ≧ ∞ ∴ ≡ ≒ √ ∽ ∧ ∫ Σ ^

Currency

$ € £ Fr ¢ ¥ ₡

DoubleFigure

00 01 … 09 10 11 … 98 99

Greek

Α Β Γ Δ Ε Ζ Η Θ Ι Κ Λ Μ Ν Ξ Ο Π Ρ Σ Τ Υ Φ Χ Ψ
Ω α β γ δ ε ζ η θ ι κ λ μ ν ξ ο π ρ σ τ υ φ χ
ψ ω

Office

Safety

Facility

Adding frames

Frames include borders and fun symbols for activities and special occasions.

1. Press [ ] to display **Frame**, then press [ ] to select it.
2. Press [ ] to scroll through the options, then press [ ] or enter the frame number to select the frame you want to use.

You can choose from the following frames:



37		38		39		40		41		42							
43		44		45		46		47		48							
49		50		51		52		53		54							
55		56		57		58		59		60							
61		62		63		64		65		66							
67		68		69		70		71		72							
73		74		75		76		77		78							
79		80		81		82		83		84							
85		86		87		88		89										

Changing the font size

You can change the size for the letters, numbers, and symbols on your ribbon.

1. Press [A↘a].
2. Press [▶] to select a 1-line or 2-line layout, then press [↵]. You see squares representing the text, and numbers representing the available size variations.

   Note: If you select a 2-line layout, you can make each line a different size. However, the larger font sizes may not be available.
3. Press [▶] to scroll through the available sizes, then press [↵] to select the one you want to use.

Tip: The size you select is indicated on the display.

Changing the font

Go from simple to ornate, and create the right impression for each ribbon design.

1. Press [AA𝒜].
2. Press [▶] to scroll through the fonts, then press [↵] to select the one you want.

The font you select will apply to the entire ribbon.

You can choose from the following fonts:



Changing the font style

Personalize your ribbon text with italic, shadow, and outline effects.

1. Press [AAA].
2. Press [▶] to scroll through the styles, then press [↵] to select the one you want.

Note: Styles applied to small or elaborate characters may not print clearly.

You can choose from the following font styles:



Printing Ribbons

1. Press [🖨] to print the current ribbon design.

   The length of the ribbon and the number of copies shows on the display while the ribbon prints.
2. When printing stops, press the ✂ Cut button.

Warning: Do not press the ✂ Cut button until the tape stops moving or the tape cartridge may be damaged.

- To select a saved ribbon for printing, press [⇧] + [▼] or [⇧] + [▲] to scroll through your ribbon designs, then press [↵] to select the one you want.
- To preview your ribbon before printing, press [👁]. The text scrolls across the display.

Note: Only the text and the length of the ribbon can be previewed. The actual print image will not show on the display.

Printing multiple copies

You can print up to 9 copies of a design on one ribbon. This lets you create longer ribbons for larger bows and wrapping around gifts.

1. Press [ ]. You see 2-9 on the display.
2. Press a number key to enter the number of copies (2-9).
3. Press [ ]. The length of the ribbon design and the number of copies shows on the display while the ribbon prints.
4. When printing stops, press the Cut button to cut the ribbon.

Customizing Your Ribbons

You can customize your ribbons by creating special effects, such as vertical and mirrored text. In addition, you can adjust the font width, spacing, and print density. You can also add punctuation and accented characters to the text.

Creating vertical text

You can specify vertical orientation either before or after you enter the text for a ribbon.

1. Press [ ].
2. Press [▶] repeatedly until **Vertical** appears, then press [ ] to select it.
3. Press [▶] to select **On**, then press [ ].

Adding space between characters

You can add extra space between the letters, numbers, and symbols on your ribbon.

1. Press [Menu].
2. Press [▶] until you see **Char. spacing**, then press [↵] to select it.
3. Press [▶] to change from **Narrow** to **Wide**, then press [↵].

Increasing print density

You can make the print on your ribbons darker if necessary.

1. When the power is off, press [Print] + [Power]. **Print density** appears on the display.
2. Press [↵].
3. Press [▶] to adjust the print density, then press [↵] to select the density you want.

Selecting narrow characters

You can change from normal characters and symbols to narrow ones.

1. Press [Menu].
2. Press [▶] until you see **Narrow**, then press [↵] to select it.
3. Press [▶] to change from **Normal** to **Narrow**, then press [↵].

Adding punctuation

In addition to the basic punctuation marks shown on the keyboard, you can select from two more groups of punctuation marks, as shown below:

Group 1 ; ( ) < > [ ] { }

Group 2 " + − = \ ^ _ |

- Press [!?] repeatedly to scroll through the first group of marks, then press [↵] to select the desired mark.
- Press [⇧] + [!?], then press [!?] repeatedly to scroll through the second group of marks. Then press [↵] to select the desired mark.

Adding letters with an accent mark

You can choose from a list of accented letters on the display.

1. Enter the letter that needs an accent mark.
2. Press [ÄÀÂ]. A list of options appears on the display (for example, ÀÁÂ).
3. Press [◄] or [►] to highlight an item, then press [↵] to select it.

Customizing the length of ribbons

You can specify the length of your ribbons (up to 15 in.)

1. Press [Menu].
2. Press [►] until you see **Label length**, then press [↵] to select it.
3. Press [►] to select a value up to 15 in. (40 cm), then press [↵].

Tip: Selecting Auto will adjust the length automatically.

Using mirror-image text

Create unique ribbons with mirror-image text.

1. Press [Menu] .
2. Press [►] repeatedly until **Mirror print** appears, then press [↵] to select it.

3. Press [▶] to select **On**, then press [↵].

Creating sequentially numbered ribbons

You can create a ribbon, and then print numbered copies of it.



1. Create your ribbon as described on page 7.
2. Press [◀] or [▶] to move the cursor where you want to add the number, then press [⇧] + [★⚠✎].
3. Enter the number for the first ribbon, then press [↵].
4. Follow the instructions on page 17 to print multiple copies of the ribbon. Each copy is numbered in order.

Sample Projects

You can use personalized ribbons for hundreds of decoration and gift projects. This section includes a few ideas to get you started.

Favor bags

Make customized favor bags for wedding or baby showers, holidays, birthdays, and other special occasions. You can add symbols and/or a frame on the ribbon to match the party's theme.

1. Create your ribbon.

   For weddings and showers, enter the couple's names, add spaces, then add the wedding date. Add an appropriate frame.

   If you need a longer ribbon, print several copies of your design, following the instructions on page 17.

2. Cut a 12-inch circle of tulle, cellophane, or other lightweight material.
3. Drop a small amount of candy in the center of the circle.
4. Wrap the material around the candy, and use your printed ribbon to tie it together with a knot or bow. Make sure you twist the ribbon when you tie it so you can see the printed design on both ends.

Hair bows or ponytail holders

Print personalized hair decorations for your favorite little girl or matching ponytail holders for the whole team.

1. Enter the text and symbols.

   If you need a longer ribbon, print several copies of your design, following the instructions on page 17.

2. Tie the ribbon around an elastic ponytail holder. Or, tie a bow and glue it to a plastic hair clip.

   Make sure you twist the ribbon when tying it so you can see the printed design on both ends.

Ornaments with ribbon hangers

Printed ribbon makes a perfect Christmas ornament hanger.



1. Create your ribbon design with vertical text and symbols. Add space at the beginning to allow for tying.
2. Make sure you have enough space at the end of the ribbon so that you can loop it through the ornament hook.

   Press ⇧ + ⎙ to feed about an inch. Press these buttons repeatedly to add more length.
3. Print your ribbon.
4. Thread the ribbon through the ornament hook and tie the ends together as shown.
5. Hang your ornament on the tree.

Greeting cards

Add ribbon embellishments to personalize a ready-made card or create your own card.



1. Enter the text and symbols for your greeting.
2. Print the ribbon or ribbons.
3. Trim the ribbons if necessary, then glue them to the card.

Adjusting the Display

You can adjust the following display settings:

Contrast: Adjusts the density of the fonts on the display.

Language: Changes the language of the settings and messages on the display.

inch:cm: Selects the unit of measurement.

1. Press [⇧] + [Ⓐ].
2. Press [▶] to highlight a setting, then press [↵] to select it.
3. Press [▶] to highlight the option you want, then press [↵] to select it.

Cleaning the Printer

Use a dry, soft cloth or, for stubborn stains, a moist cloth that has been wrung dry.

Caution: Never use chemicals or solvents such as benzine, thinner, or alcohol, or use a chemical duster. This could damage your product.

Cleaning the print head

If the print becomes faint or distorted, the print head may need cleaning.

Remove the tape cartridge and clean the print head using a cotton swab moistened with rubbing alcohol, as shown below:



Solving Problems

If you have a problem with your LabelWorks, check the display or the troubleshooting suggestions below.

Error messages

Insert tape	Turn the power off and install a tape cartridge.
Check battery	The batteries may be running out or installed incorrectly, non-alkaline batteries are being used with alkaline batteries, or old and new batteries are being used together. Turn the power off and replace batteries with new ones, or use the optional AC adapter. Make sure new batteries are installed correctly.
Too many lines	You have exceeded the maximum number of lines (2). Press ⌫ to delete the lines indicated.
Seq. num. only 1	Sequence numbers have already been set. You can only enter one sequence number per ribbon.
Txt too long-OK?	Entered text is too long for the specified ribbon length. Press [ ] and adjust the ribbon length or make text shorter.
Overheated!	The print head is too hot. Turn the power off and take out the tape cartridge. Allow the print head to cool before trying to print again.
Cover open!	If you open the rear cover while the power is on, this message displays and the power turns off automatically. Always turn the power off before opening the rear cover.
Delete all text?	When creating a ribbon with a special format, the current text will be deleted. Press [ ] to delete the text and show the special format.
Motor error!	An error occurred in the motor operation. Turn the power off, then turn it back on. If the same message appears, turn the power off again and contact Epson for technical support.

Problems and solutions

Check the solutions below if you are having trouble using your product.

The product does not function normally

The product may stop functioning due to static electricity or other causes. If your product does not function normally (for example, the power doesn't turn on/off or the display is distorted), reset your product by following the procedure below.

Warning: Resetting your product will erase all saved labels and formatting and return your product to default settings.

1. Press ⏻ to turn the power off.
2. Press and hold ↵ + ⌫, and press ⏻.
3. When a message appears, press ↵ (to cancel, press any other button).

The product will be reset.

Power is on but no images appear on the display

- Make sure the batteries are correctly seated.
- Replace the batteries with new ones, or use the optional AC adapter (C52CB73020).
- If you are using the AC adapter, make sure that it is securely connected to both the wall outlet and the product.
- Adjust the contrast as described on page 23.

The display turns off

- The power turns off automatically if the product is idle for more than 5 minutes.
- If an incorrect button sequence is entered, the display may flicker or turn off for an instant.

Nothing prints

- Make sure text has been entered.
- Replace the tape cartridge if necessary.
- Check the display for an error message and perform the suggested solution.
- Replace the batteries with new ones, or use the optional AC adapter (C52CB73020).
- Make sure the rear cover is closed.

Characters do not print properly

- Make sure the tape cartridge is correctly seated.
- Clean the print head.
- Change the font (sometimes symbols do not print properly when certain fonts are selected).

Printing stops in the middle of text

- Install a new tape cartridge.
- Replace the batteries or use the optional AC adapter (C52CB73020).

Saved ribbons are gone

- Make sure you have not accidentally deleted the design.
- If the product is reset, all of the previously entered text will be deleted.
- If the AC adapter is unplugged or the batteries are removed during operation, the text may be deleted.

Epson Technical Support

Visit epson.com/support (U.S.) or epson.ca/support (Canada) where you can view manuals, get FAQs, or e-mail Epson.

To speak with a support specialist, call:

U.S.: (562) 276-7245, 6 am to 8 pm, Pacific Time, Monday through Friday, and 7 am to 4 pm, Saturday.

Canada: (905) 709-2567, 6 am to 8 pm, Pacific Time, Monday through Friday.

Days and hours of support are subject to change without notice. Toll or long distance charges may apply.

Recycling

Epson offers a recycling program for end of life products. Please go to www.epson.com/recycle for information on how to return your products for proper disposal.

Purchase supplies and accessories

Epson offers a wide array of ribbons and tapes for multiple uses. For a complete list of available tapes, including additional widths, visit epson.com/LW300Tapes.

You can purchase tape cartridges and accessories at:

www.epson.com/LabelWorks (U.S. sales) or **www.epson.ca/LabelWorks** (Canadian sales).

You can also purchase supplies from an Epson authorized reseller. To find the nearest one, call 800-GO-EPSON (800-463-7766).

Registration

To receive special offers and updates on new ribbons and tapes, make sure you register your LabelWorks printer.

Go to **www.epson.com/LabelWorks** and select **Product Registration.**

Specifications

Dimensions (approximate)	Width: 5.70 inches (145 mm) Depth: 5.90 inches (150 mm) Height: 2.16 inches (55 mm)
Weight (approximate)	14 oz (400 g) (excluding batteries and tape cartridge)
Operating temperature	50 to 95 ºF (10 to 35 ºC)
Storage temperature	14 to 131 ºF (-10 to 55 ºC)
Power supply - batteries	AAA alkaline battery x 6
Power supply - optional AC adapter	Model: C52CB73020 Manufacturer: Seiko Epson Corp. Input: AC100-240 V, 0.3 A, 50-60Hz Output: DC 6.5 V, 1.5 A Total output power: 10 W
Supported tape widths (approximate)	1/4" (6 mm) 3/8" (9 mm) 1/2" (12 mm)

Storing Your Kit



Notices

Safety instructions

Before using your product, read the following safety instructions to make sure you use it safely and effectively.

- Always use the product as instructed in the manual. Otherwise, damage or injury may occur.
- Do not subject the product to any strong force or shock such as dropping, hitting, or standing on the product.
- Do not spill liquid on the product or use the product with wet hands.
- Do not open any covers on the product other than the rear cover.
- Do not touch the print head.
- Turn the product off, unplug the AC adapter and remove the batteries, and refer servicing to qualified service personnel under the following conditions: if liquid or foreign objects get inside the product; if the product does not operate normally or exhibits a distinct change in performance. Continuing to use the product may result in damage or injury.
- To avoid injury, keep your fingers away from the label exit slot when printing or using the cutter.
- Avoid locations that are subject to rapid changes in heat or humidity, shocks or vibrations, or dust.
- Do not place or store the product in the following locations: outdoors or in direct sunlight; near sources of excessive heat, humidity, shocks, vibrations, or dust; where it may get wet or be exposed to excessive humidity; on an unstable place such as a shaky or inclined surface; near potential sources of electromagnetic interference such as loudspeakers or the base units of cordless telephones.
- The product and product manuals may come packaged in plastic bags. Keep plastic bags away from small children to avoid any risk of suffocation.
- If you will not be using the product for a long period, unplug the power cord and remove the batteries.
- Before cleaning, unplug the power cord and remove the batteries. Use only a dry, soft cloth to clean the product; do not use liquid or chemical cleaners.

- Operate the keyboard gently.
- Take care not to cut your fingers when cutting a tape with scissors.

Batteries

- Use batteries properly to avoid injury or fire caused by leaking, overheating, explosion, erosion, or damage to the product.
- Keep batteries out of reach of children. If battery acid gets into your eyes or on your skin, immediately rinse the affected area thoroughly with water and seek medical treatment. If a battery is swallowed, seek medical treatment immediately.
- When replacing batteries, follow these safety instructions:
  - If battery acid leaks from a battery, wipe it off with a cloth and replace the battery with a new one.
  - Do not use new and old batteries together or mix different types of batteries.
  - Use only AAA alkaline batteries. You cannot use rechargeable batteries with your product.
  - Insert batteries so that the polarities (+ and -) are correct.
  - Remove dead batteries promptly.
  - Do not heat batteries or throw them in fire or water.
  - Do not remove batteries with metal objects such as tweezers or the tip of a pen.
- Make sure to follow local battery disposal regulations.

AC adapter

- Use only model C52CB73020 AC adapter and power cord with your product. Do not use the AC adapter with any other equipment and use only with the specified voltage. Using the wrong AC adapter and power cord may result in damage, overheating, fire, or electric shock.
- Plug the power cord firmly into the outlet. When removing the plug from the outlet, grasp the plug firmly and do not yank on the cord.
- Make sure the plug is not dusty when inserting it into an outlet.
- Do not hold the plug with wet hands.
- Do not make any modifications to the AC adapter or power cord.

- Place the AC adapter and power cord to avoid abrasions, cuts, fraying, crimping, and kinking. Do not place heavy objects on top of the AC adapter or power cord.
- Make sure the AC adapter has sufficient ventilation so that it doesn't overheat and become damaged. Do not crowd it with too many other adapters or cords.
- Do not forcibly bend or twist the power cord.
- Do not place the AC adapter or power cord near a heater.
- To avoid fire or electric shock, do not use a damaged AC adapter or power cord.
- Turn off the product before unplugging the AC adapter. Otherwise, it may not function properly or may become damaged.

Tape cartridges

- Use only compatible LC TAPE tape cartridges.
- To avoid damage, do not drop or disassemble tape cartridges.
- Feed the tape using the ⇧ + ⎙ buttons. Do not forcibly pull out the tape. Otherwise, you may damage the tape cartridge.
- Do not try to print with an empty tape cartridge; this may overheat the print head and damage the product.

Note: Tape cartridges contain ink ribbons. Make sure to follow local ink disposal regulations.

About printed labels

Attached labels and adhesive are affected by the type of surface and by environmental conditions such as humidity and heat. Labels may peel off, curl, or fade; printed characters may fade; color may be left behind after removing the label; adhesive may become stuck to the attached surface.

Epson is not responsible for any damage or loss caused by labels or adhesive.

FCC Compliance Statement

For United States Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For Canadian Users

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Epson America, Inc. Limited Warranty

What Is Covered: Epson America, Inc. ("Epson") warrants to the original retail purchaser that the Epson label-printing device and its consumables and accessories covered by this limited warranty statement (each, a "product"), if purchased and operated only in the United States, Canada, or Puerto Rico, will be free from defects in workmanship and materials for a period of one (1) year from the date of original purchase, in the case of the label-printing device, and for a period of thirty (30) days from the date of original purchase, in the case of its consumables or accessories. Consumables include label and tape rolls and cassettes. Accessories include an AC adaptor. For consumables, the warranty covers only mechanical defects in workmanship and materials. For warranty service, you must provide proof of the date of original purchase.

What Epson Will Do To Correct Problems: Should your Epson product prove defective during the warranty period, please call the Epson Connection at (562) 276-7245 (U.S. and Puerto Rico) or (905) 709-2567 (Canada) for warranty repair instructions and return authorization. An Epson service technician will provide telephone diagnostic service to determine whether the

product requires service. If service is needed, Epson will, at its option, exchange or repair the product without charge for parts or labor. If Epson authorizes an exchange for the defective unit, Epson will ship a replacement product to you, freight prepaid, so long as you use an address in the United States, Canada, or Puerto Rico. Shipments to other locations will be made freight collect. You are responsible for securely packaging the defective unit and returning it to Epson within five (5) working days of receipt of the replacement. Epson requires a debit or a credit card number to secure the cost of the replacement product in the event that you fail to return the defective one. If Epson authorizes repair instead of exchange, Epson will direct you to send your product to Epson or its authorized service center, where the product will be repaired and sent back to you. You are responsible for packing the product and for all costs to and from the Epson authorized service center. When warranty service involves the exchange of the product or a part, the item replaced becomes Epson property. The replacement product or part may be new or refurbished to the Epson standard of quality, and, at Epson's option, may be another model of like kind and quality. Exchange products and parts assume the remaining warranty period of your original product covered by this limited warranty.

What This Warranty Does Not Cover: This warranty covers only normal use in the United States, Canada, or Puerto Rico. Using this product for continuous production or similar high duty purposes is not considered normal use; damage, maintenance or service from such use will not be covered under this warranty. This warranty is not transferable. This warranty does not cover damage to the Epson product caused by parts or supplies not manufactured, distributed or certified by Epson. This warranty does not cover third party parts, components, or peripheral devices added to the Epson product after its shipment from Epson, e.g., dealer or user-added boards or components. Epson is not responsible for warranty service should the Epson label or logo or the rating label or serial number be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, improper installation, neglect, improper shipping, damage caused by disasters such as fire, flood, and lightning, improper electrical current, software problems, interaction with non-Epson products, or service other than by an Epson Authorized Servicer. If a claimed defect cannot be identified or reproduced, you will be held responsible for the costs incurred.

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENTS OR REPRESENTATIONS MADE BY ANY OTHER PERSON OR FIRM ARE VOID. IN NO EVENT SHALL EPSON OR ITS AFFILIATES BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR INABILITY TO USE THE EPSON PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY. IN NO EVENT SHALL EPSON OR ITS AFFILIATES BE LIABLE FOR DAMAGES OF ANY KIND IN EXCESS OF THE ORIGINAL RETAIL PURCHASE PRICE OF THE PRODUCT.

In Canada, warranties include both warranties and conditions.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

To find the Epson Authorized Reseller nearest you, visit our website at http://www.epson.com.

To find the Epson Customer Care Center nearest you, visit http://www.epson.com/support.

You can also write to Epson America, Inc., P.O. Box 93012, Long Beach, CA 90809-3012.

Trademarks

EPSON is a registered trademark and EPSON Exceed Your Vision is a registered logomark of Seiko Epson Corporation.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

This information is subject to change without notice.

© 2013 Epson America, Inc. 3/13 CPD-37149

Printed in USA


Font size
Frame
Design number
01 ABC 2
a A
ÁÄÂ
The black marks indicate features you are using
2-line design
Battery level

LabelWorks tapes available at www.epson.com/LabelWorks

TAPE	1/4 inch (6 mm)	3/8 inch (9 mm)	1/2 inch (12 mm)
Ribbon			LC-4JBK5, LC-4PBK5, LC-4LBK5, LC-4HKK5, LC-4NKK5, LC-4KBK5
Standard labels	LC-2WBN9	LC-3WBN9, LC-3WLN9, LC-3WRN9	LC-4WBN9, LC-4BWV9, LC-4WLN9, LC-4BKP9, LC-4WRN9
Clear			LC-4TBN9, LC-4TKN9
Metallic			LC-4SBM9, LC-4KBM9
Iron-on			LC-4WBQ5, LC-4PBQ5, LC-4LBQ5
Glow-in-the-Dark			LC-4ZBU1
Strong Adhesive			LC-4WBW9, LC-4YBW9
Pearlized			LC-4LBL9, LC-4GBL9, LC-4RBL9